Simon XT Quick Reference Card

the instructions on this card will guide you through the basic functions of your simon XT panel. For additional questions, you can consult the user manual or call technical support at 866.290.6769

Know How

To properly execute the items on this sheet, you first need to know which keys are which. Look at the picture below.
1. Doors & Windows / 2. Motions / 3. Disarm / 4. Status
5. Up Arrow / 6. Down Arrow / 7. OK button.

Change Your Master Code

To change the master code on your Simon XT panel, complete the following steps:

1. These steps must be done in quick fashion, otherwise it will not work.
2. Press the down arrow until the LCD screen says "system programming", then press OK, followed by the current master code.
3. The screen will say "access codes"
4. Press OK.
5. To change the current Master Code, press OK, then the access code will be flashing. Type in the new 4 digit code, followed by OK.
6. Press status a couple of times to exit system programming.

Enable & Disable Chime Function

To turn the chime on or off on your Simon XT Panel, complete the following steps:

1. On your alarm panel, press the down arrow until it says Chime [on] or Chime [off], press OK, followed by the up or down arrow. The panel will toggle between Chime [on] and Chime [off].
2. Press OK to confirm.

Bypass Sensors

To bypass a sensor using your Simon XT panel, complete the following steps:

1. Arm your security system, leaving the door or window open that you would like to bypass.
2. The system will tell you which sensors are being bypassed as the system arms.
3. Once you disarm the system, the sensors will be unbypassed once again.

My Panel Started Beeping

Your Simon XT panel will alert you when there is activity on the panel. The panel is beeping because it wants you to *acknowledge* the alert, not necessarily because there is a major problem.
To make your panel stop beeping:

1. Press the Status button, and the panel will tell you what the current system status is. (Low Battery, check system, etc).
2. Press Disarm, followed by your Master Code.
3. You may need to repeat a couple of times until the system stops beeping.

Set the Date and Time

To set the date and time on your Simon XT panel, complete the following steps:

1. Press the Up arrow until the LCD screen says "Set Clock" and press OK.
2. Type in your 4 digit Master Code and press OK.
3. Display will now flash the hours. To adjust the hour, press the up or down arrows until you have the accurate hour. Press OK.
4. Display will now flash the minutes. To adjust the minutes, press the up or down arrows until you have the accurate minutes. Press OK.
5. Display will now flash AM/PM. To adjust, press the up or down arrows to toggle correctly. Press OK.